





















1  1PC	2  1PC	3  1PC	4  1PC
5  1PC	6  1PC	7  1PC	8  2PCS
9  1PC	10  1PC	11  1PC	12  1PC
13  2PCS	14  2PCS	A  M6x35mm 14PCS	B  M15x10mm 20PCS
C  M6x30mm 34PCS	D  M6x50mm 4PCS	E  6PCS	F  6PCS
G  6PCS	H  M4x35mm 22PCS	I  M4x25mm 4PCS	J  40PCS
K  1PC			




1

- Ax4
- Bx2
- Cx8
- Dx4
- Hx4




2

- Bx2
- Cx6
- Hx2



3

Hx6




4

Cx8

Gx4


Hx6




5

Cx6
Ex4
Fx4


Direction A






Pay attention to the installation direction of component F.

Direction B




6


Ax6
Cx2
Ex2
Fx2



Pay attention to the installation direction of component F.



Direction A




Direction B


7


Bx6

Direction A

Direction B








8

Ax4

Direction A

Direction B



9


Cx2

Gx2

Hx4

Direction A

Direction B




10

Bx4

Direction A

Direction B




11

Cx1

Ix2

Direction A


Direction B




12

Bx6

Jx40



All holes that leak on the visible surface can be covered with pressure-sensitive adhesive J.



13

Cx1

Ix2

Direction A

Direction B

